

1.1 ***NET Config Set network configuration***

This command can be used to configure board network setting.

Abbreviated ASCII Syntax:

CONFIG ETH1 DHCP
CONFIG ETH1 192.168.0.100 192.168.0.1 255.255.255.0 192.168.0.1

Header	Name	Parameter	Description
CONFIG	ETH1	DHCP	Use DHCP
		IPv4 list	IP Gateway NetMask DNS_Server

1.2 ***Configure network port***

This command can be used to configure TCP port.

Abbreviated ASCII Syntax:

CONFIG ICOM1 TCP 40001
CONFIG COM1 TCP 192.168.0.2 80001

Header	Serial Port	Parameter	Description
CONFIG	ICOM1 ICOM2 ICOM3	Disable	Disable the TCP/IP client function
		Protocol	TCP or UDP. Default Setting is TCP protocol.
		IP	Config the IPv4 address
		Port Number	Config the port number